

READING THE METERS

Copiers

- Open the unit to expose the control board
- Press **YES** and **NO** buttons on the control board simultaneously and release

The display will begin flashing "Meter E" and will show the number of cash copies made

- Pressing the YES button once will then bring up the next display

The table below shows the sequence of information displayed by continuing to press the YES button once for each item:

Meter E	Number of 8 ½ x 11 black & white cash copies made*
Bypass E	Number of 8 ½ x 11 black & white copies made on "bypass"*
Card E	Number of 8 ½ x 11 black & white copies paid by card*
Meter F	Number of 8 ½ x 14 or 11 x 17 black & white cash copies made*
Bypass F	Number of 8 ½ x 14 or 11 x 17 black & white copies on "bypass"
Card F	Number of 8 ½ x 14 or 11 x 17 black & white copies paid by card*
Meter G	Number of 8 ½ x 11 color cash copies made*
Bypass G	Number of 8 ½ x 11 color copies on "bypass"*
Card G	Number of 8 ½ x 11 color copies paid by card*
Meter H	Number of 8 ½ x 14 or 11 x 17 color cash copies*
Bypass H	Number of 8 ½ x 14 or 11 x 17 color copies on "bypass"*
Card H	Number of 8 ½ x 14 or 11 x 17 color copies paid by card*
Card Add / \$xx.xx	Amount of value added to cards*
Cash / \$xx.xx	Amount of cash copies made since data last cleared
Box / \$xx.xx	Amount of money routed to coin drawer since data last cleared
Bill / \$xx.xx	Total bills accepted since data last cleared
Tube / \$xx.xx	Amount currently in change tubes

***These meters are NOT resettable**

(Before proceeding further please read "RESETTING THE CASH TOTALS")

When you have completed your review of the information in the meters once, the display will read "Done?".

- Pressing the **YES** button will place the system back into the vending mode.
- Pressing **NO** will place you in the dispense mode.

RESETTING THE CASH TOTALS

While the "Tube" amount is displayed, the cash meters may be reset to \$00.00

- Press and hold the **NO** button
- Press the **YES** button and hold **both** for five seconds

The meters are cleared and the display will show "Cash" and a \$00.00 value

- Press the **YES** button once each for "Box", "Bill", and "Tube"

The "Box" and "Bill" meters are cleared and the display will show

\$00.00 values for "Box" and "Bill" and "\$XX.xx" (the actual value in the tubes).

The display will read "Done?"

(Before proceeding further please read "DISPENSING COINS")

- Press the YES button once to return to vending mode and NO to proceed to dispensing coins.