

TOTALLING THE SYSTEM, READING THE METERS AND REMOVING THE CASH

READING THE METERS

-Open the unit to expose the PC board

-Press the **YES** and **NO** buttons inside the cabinet simultaneously and release

The display will begin flashing "Cash" and will show the amount of cash deposited to print.

Cards

- Pressing the **YES** button once will then bring up the next display

The table below shows the sequence of information that will be displayed by continuing to press the YES button once for each item :

CASH	###	Amount of cash deposited to pay for prints (THIS METER IS NON-RESETTABLE)
BOX	###	Amount of money routed to cash drawer since data last cleared
BILL	###	Total bills accepted since data last cleared
TUBE	###	Amount currently in change tubes

RESETTING THE BOX AND BILL TOTALS

While the "TUBE" amount is displayed (please see READING THE METERS) the box and bill counters may be reset to \$00.00 The cash meter and card add meters are rolling totals.

-Press and hold the **NO** button

-Press the **YES** button and hold both for five seconds

The meters are cleared and the display will show "BOX" and a \$00.00 value

-Press the **YES** button once each for "BOX", "BILL", and "TUBE"

The "BOX" and "BILL" meters are cleared and the display will show \$00.00 values for "BOX" and "BILL"

The "TUBE" meter can be cleared to \$00.00 by Dispensing Coins

When you have completed your review of the information in the meters once

The display will ask "DONE"

-Press the **YES** button once to return to vending mode

-Press the **NO** button will allow you to dispense coins.

PLEASE NOTE: The amount of value added to cards will not be cleared.